8.3 POWER SUPPLY REMOVAL

1. Turn off the machine and disconnect the AC power (5.1).

2. Remove the chassis hood (5.1).

3. Remove the mainboard (6.7).

4. Remove the four screws that connect the power supply and the back of the chassis. These are easier to remove from outside the back of the chassis than from inside the machine.

5. Remove the power plug from the power supply.

6. Remove the tie wraps from the plastic standoffs.

7. Remove the power supply.

POWER SUPPLY INSTALLATION

1. Position the power supply inside the chassis so that the four plastic standoffs are aligned with the four mounting holes in the chassis. Be certain that the power connector is on the side nearest the drives.

2. Place the tie wraps on the plastic standoffs.

3. Insert four screws through the rear of the chassis and into the plastic standoffs of the power supply.

4. Tighten the screws securely.

5. Replace the power connector.

6. Replace the mainboard (6.7).

7. Replace the chassis hood (5.1).