9.5 DISKETTE DRIVE REMOVAL

1. Turn off the machine and disconnect the AC power (5.1).
2. Remove the chassis hood (5.1).
3. Remove the data cable, power plug, and ground wire from the rear of the drive.
4. Remove the four screws that secure the drive in the drive shield.
5. Slide the drive out of the drive shield through the front of the machine.

   Note: If the drive is hard to slide out of the drive shield unit, loosen the screws holding the other drive in place.

DISKETTE DRIVE INSTALLATION

1. Configure the new drive. (A Drive or B Drive) Refer to pages 9--5 to 9--8.
2. Slide the drive into the drive shield.
3. Align the mounting holes on the drive with the holes on the drive shield.
4. Insert four screws through the shield and into the drive mounting holes.
5. After all the screws are inserted, tighten them securely.
6. Replace the data cable, power plug, and ground wire on the rear of the new drive.
7. Replace the chassis hood.