14.2 DISKETTE DRIVE REMOVAL

1. Remove the top chassis cover (5.1).

2. Remove the drive support unit from the chassis. There are three screws in the front and three screws in the rear.

3. Remove the ribbon cable and the power plugs from the drives.

4. Lift the drive support unit (drives still attached) off the chassis.

5. To remove either drive from the drive support unit, turn the unit over and remove the four screws that attach the specific drive to the support unit.

DISKETTE DRIVE REPLACEMENT

1. Align the drive mounting holes with the mounting holes in the drive support unit.

2. Insert four screws into the drive support unit and into the drive. Tighten these screws securely.

3. Set the drive support unit on the chassis and align the mounting holes in the support unit with those in the chassis.

4. Insert three screws into the front mounting holes and three screws into the rear mounting holes. Tighten these securely.

5. Replace the ribbon cable and the power plugs on the drives.