15.2 KAYPRO 2 AND 4 SYMPTOM—FIX GUIDE

CONDITION	POSSIBLE CAUSE	RECOMMENDED ACTION
No power, no lights, no video	Power cord not plugged in	Check all cord connections
	Fuse is blown	Replace fuse
	Mainboard not getting power	Check harness connections; check for proper voltages; replace either harness or power supply
	Defective mainboard	Replace mainboard
	Defective fuse holder	Replace fuse holder
	Power switch shorted internally	Replace power switch
	Power supply jumpered for wrong supply	Correct jumpering on power supply
	Defective power supply	Replace power supply
	Defective harness	Replace harness
Fuse blows when power is turned on	Defective power supply	Disconnect all modules from power supply; replace power supply if fuse still blows
	One module has a short	Disconnect all modules, replace fuse, and re-connect modules, one at a time, until fuse blows. Replace that module
	Defective harness	Replace harness
High-pitched squeal or "chirp"	One module is shorted	Unplug modules,one at a time, from the harness. Replace the module whose unplugging causes the noise to stop