KAYPRO 2 AND 4 SYMPTOM—FIX GUIDE (CONT'D)

CONDITION	POSSIBLE CAUSE	RECOMMENDED ACTION
Power LED flickers	Shorted module	Disconnect modules from power, one at a time, until LED stays on; replace module whose unplugging caused LED to stay on.
	Defective power supply	Replace power supply
	Defective harness	Replace harness
No video display, or poor quality display	Brightness not adjusted	Turn up brightness knob on rear of chassis; adjust brightness pot on CRT board, if necessary
	CRT not connected	Check all connections to CRT; be sure plug on rear of CRT tube is square
	Defective CRT	Replace CRT assembly
	Defective mainboard	Replace mainboard
	Defective power supply	Replace power supply
	Defective harness	Replace harness
Video is on, but screen is filled with "garbage" characters	Defective mainboard	Replace mainboard
	Reset harness shorted to chassis	Check lugs of reset button for grounding to inside of chassis
	Defective reset harness	Replace reset harness