KAYPRO ROBIE SYMPTOM—FIX GUIDE (CON'T.)

CONDITION	POSSIBLE CAUSE	RECOMMENDED ACTION
Will not boot	Defective mainboard	Replace mainboard
	Defective drive A	Replace drive A
	Defective data cable	Replace data cable
Both drive LEDs are on, won't boot	Problem on power-up	Reset machine
	Diskette has no CP/M	Try known good sysgenned diskette
	Defective mainboard	Replace mainboard
	Select jumpers on drives incorrect	Check select jumpers
Drive A LED only on during reset	Drive select jumpering incorrect	Check jumpering on drive A
No LED on drive A at any time	Data cable poorly connected	Check all connections on data cable
	Defective data cable	Replace data cable
	Defective drive A	Replace drive A
	Defective mainboard	Replace mainboard
Computer boots CP/M, but no master menu appears	Defective diskette	Try known good, sysgenned diskette
	Defective drive A	Replace drive A
	Defective mainboard	Replace mainboard
Rattling sound from drive when accessing	Defective drive	Replace the diskette drive
	Defective mainboard	Replace mainboard