HARD DRIVE OR FLOPPY INSTALLATION FOR KAYPRO 10

1. Configure the new drive. Refer to page 10--3 for the hard drive, pages 9--5 to 9--8 for the floppy drive.

2. Slide the drive into the shield so that the mounting holes in the drive are aligned with those in the shield.

3. Insert two screws through the top of the shield and into the mounting holes of the drive.

4. Tighten these securely.

5. Insert two screws through the bottom of the shield and into the mounting holes of the drive.

6. Tighten these securely.

7. Replace the ribbon cable(s), power plug and ground wire.

8. Slide the entire drive shield unit into the chassis.

9. Align the mounting holes in the drive shield with those in the chassis.

10. Insert the six screws through the mounting holes and tighten securely.

11. Replace the two diagonal braces.

12. Replace the ribbon cable(s) on the mainboard.

13. Replace the chassis hood.