


STEP 2


Remove an available slot cover from the chassis of the computer.



STEP 3


Plug one end of the cable to the 50-pin internal Ultra SCSI connector on the SCSI Card 2940U2W.

50-pin Internal Ultra SCSI Connector




STEP 4

Secure the mounting bracket of the cable to the exposed card slot opening in the chassis of the computer.




STEP 5

Connect one end of the external SCSI cable to the 50-pin external connector on the internal-to-external cable.




STEP 6

Connect the other end of the external SCSI cable to a SCSI connector on the back of the external SCSI peripheral. If you are installing only one external peripheral, terminate the peripheral and skip to Step 8.



STEP 7

Connect other external peripherals by connecting each peripheral to the previous one until all peripherals are connected. The peripheral at the end of the chain must be the only external peripheral terminated.



STEP 8

Connect all power cables to the external peripherals.

